

Custom Speaker Pods

'94 – up E-Z-GO
Front Kick Panel Pod Installation

1. Peel Back the rubber matt from the channel.



2. Place the speaker pod in its location and mark the channel with a pencil.



3. Cut along the pencil mark and remove the top portion of the channel.



4. Place the rubber mat back into the channel and its original location. Place the speaker pod on top of the mat. Mark the inner contours of the pod with a pencil, being sure the marks are visible on the rubber mat.



5. Cut along the pencil mark with heavy duty scissors or a box cutter. Note: Do not cut into the plastic flooring below!



6. Remove the piece of cut rubber.



7. Predrill holes through the speaker pod and into the kickplate of the golf cart.



8. Attach the speaker pod to the golf cart. In this case we used a rivet gun, but you can also use the hardware supplied with the unit.



9. Mark the holes for your speaker and tweeter. In this instance we installed a 4" speaker and standard tweeter. Note: If you decide to install a larger 5 1/4" speaker, it may be necessary to trim the speaker cover in order to get it to fit properly.



10. Installation of your speaker pod is complete.



11. For the drivers' side, first remove the steering wheel and follow the same technique described above.

