

Custom Speaker Pods

'94 – up E-Z-GO Front Kick Panel 6.5" Pod Installation

1. Remove the steering wheel from the steering column.



2. Place the speaker pod in its location overtop the floor mat and mark the area to cut away with chalk. Follow the contours of the pod from inside the pod with the chalk.



3. Cut along the chalk line and remove the piece of floor mat. Note: **Do not cut into the plastic flooring below!**



4. Place the rubber mat back into the channel and its original location to check for fitment. Some extra trimming may be necessary.



5. Pre-drill holes for mounting.



6. You may use wood screws (which are supplied) or rivets (will have to be purchased separately with a proper rivet gun). In this case we used rivets and a rivet gun.



7. With the base of the speaker pod now mounted we will move onto the side of the speaker pod.



8. Pre-drill holes through the speaker pod and into the side of the dash panel. **Note: Be sure to align the side of the speaker pod with the side of the dash panel before you drill the pilot holes.**



9. Here we secured the side of the speaker pod with three rivets. We suggest the use of three or four rivets (screws) to provide a secure fit.



10. In addition two to three rivets need to be installed in the cubby hole as seen here.



11. Two more rivets or screws must be installed in order to secure the inner flange of the speaker pod as seen here.



12. Next install the passenger side using the same technique.



13. Now you can run the speaker wire to your stereo location and drill the holes for mounting the speakers. Most speakers come with a mounting template in the instructions. Tape the template over the speaker pod making sure it is centered properly, then drill your holes.



14. Congratulations, you have just completed the installation of your speaker pods.

